

# USER MANUAL

## Z203-1

### **SENECA s.r.l.**

Via Austria, 26 – 35127 – PADOVA – ITALY

Tel. +39.049.8705355 – 8705359 Fax. +39.049.8706287

Web site: [www.seneca.it](http://www.seneca.it)

Technical assistance: [supporto@seneca.it](mailto:supporto@seneca.it) (IT), [support@seneca.it](mailto:support@seneca.it) (Other)

Commercial reference: [commerciale@seneca.it](mailto:commerciale@seneca.it) (IT), [sales@seneca.it](mailto:sales@seneca.it) (Other)



This document is property of SENECA srl. Duplication and reproduction of its are forbidden (though partial), if not authorized. Contents of present documentation refers to products and technologies described in it. Though we strive for reach perfection continually, all technical data contained in this document may be modified or added due to technical and commercial needs; it's impossible eliminate mismatches and discordances completely. Contents of present documentation is anyhow subjected to periodical revision. If you have any questions don't hesitate to contact our structure or to write us to e-mail addresses as above mentioned.

# Seneca Z-PC Line module: Z203-1

The Z203-1 module is a single-phase electric-line analyzer for line voltage up to 500 Vac and line current up to 5A (35 Hz to 75 Hz). The module has an analogue output, electrical value directly proportional to selected input: voltage-type out or current-type out. The electrical value (output) is available on screw terminals and the normalized value is available on RS485 registers. A digital output is available, too, to generate a number of pulses depending on the energy increment.


## General characteristics

- It is possible to detect, with reference to the electric line and load connected to its: RMS voltage, RMS current, active power, reactive power,  $\cos\Phi$ , frequency, energy
- A FeRAM allows to recovery the energy if a black-out occurs
- Energy counter: pulse digital output, reading on Modbus register
- It is possible to change electrical start/end scale by Dip-switch (see table 1, for each type of retransmitted output) or by Modbus registers (every value)
- Normalized start/end scale between 0..+10000 (for RMS voltage, RMS current, active power), 350..750 (for frequency) or between 0..+10000 (for **absolute values** of reactive power,  $\cos\Phi$ ). It isn't possible to associate a normalized value to the energy quantity
- Possibility for connection and management by an external Current Transformer (only if Z203-1 is configurated by a configuration software).
- Easy configuration with the software Easy, downloadable from [www.seneca.it](http://www.seneca.it)
- Configuration of the module (node) address and baud-rate by Dip-Switches
- Configuration of the electrical-network nominal frequency, output type, retransmission scaling and retransmitted output by Dip-Switches
- It is possible to add/remove the module to/from RS485-bus without disconnecting the communication or power supply
- It is possible to switch automatically RS485 to RS232 or vice versa

## Features

| INPUT/RETRANSMITTED OUTPUT (ELECTRIC-NETWORK SIDE) |   |
|--|---|
| Number   | 1   |
| Accuracy   | 0.5% of E.E.S. (Voltmeter, ampere-meter, watt-meter for active power, frequency-meter)<br>Thermal stability: < 100 ppm/°K<br>EMI: < 1%                                      |
| Protection   | This module provides inputs protection against the ESD (up to 4kV)  |
| Voltage-type IN                                    | E.S.S./E.E.S.(Electrical Start/End Scale) configurable between: 0..125 Vac; 0..250 Vac; 0..500 Vac. Input impedance: 600 kΩ   |
| Current-type IN                                    | E.S.S./E.E.S.(Electrical Start/End Scale) configurable between: 0..1.25A; 0..2.5A; 0..5A. Peak factor: 3; rated current: 5 Arms; max current: 15 A. Input impedance: 3.3 mΩ |
| ANALOGUE OUTPUT                                    |   |
| Number   | 1   |
| Resolution   | 12 bits   |
| Accuracy   | 0.1% of output scale range  |
| Voltage-type OUT                                   | Output scale range configurable between: 0-10 V or 0-5 V by dip-switch, as desired by modbus register (minimum resistance that  |

|   |   |
|---|---|
|   | can be connected: 2 k $\Omega$ ). Saturation if voltage > 11 V  |
| <b>Current-type OUT</b>                                   | Output scale range configurable between: 0-20 mA or 4-20 mA by dip-switch, as desired by modbus register (max resistance that can be connected: 500 $\Omega$ ). Saturation if current > 21 mA |
| <b>DIGITAL OUTPUT: PULSE COUNTER FOR ENERGY INCREMENT</b> |   |
| <b>Number</b>   | 1   |
| <b>Type</b>   | Passive (it must be powered)  |
| <b>Range</b>  | 50 mA   |
| <b>Isolation</b>  | 1500 V <sub>peak</sub>  |
| <b>Screw terminals</b>                                    | 1, 6 (reference, common with GND of analogue output)  |
| <b>CONNECTIONS</b>  |   |
| <b>RS485 interface</b>                                    | IDC10 connector   |
| <b>RS232 interface</b>                                    | Jack stereo 3.5mm connector: plugs into COM port  |
| <b>ISOLATIONS</b>   |   |
|   | 1500Vac isolation between: power supply, ModBUS RS485/RS232 + output<br>3750Vac isolation between: input (electric line) and other parts  |




|                          |   |
|--------------------------|---|
| <b>POWER SUPPLY</b>      |   |
| <b>Supply voltage</b>    | 10 – 40 Vdc or 19 – 28 Vac ( 50Hz - 60Hz) |
| <b>Power consumption</b> | Max: 2.5 W                                |

The power supply transformer necessary to supply the module must comply with EN60742 (Isolated transformers and safety transformers requirements). To protect the power supply, it is recommended to install a fuse.


## Connections


### Input connection



Connect to the screw terminals 10 and 12 the electric network.  
Connect to the screw terminals 7 and 9 the load to analyze.

### Output connection




 Shielded cables are recommended to connect the outputs (through screw terminals: 5, 6 if voltage-type output; 4, 5 if current-type output).

### Digital output for counter

The energy value (W/h; see the register 40120/40121) is saved on FeRAM; if the digital output is activated, it sends a pulse for each unit increment of energy (pulse duration: 200 ms).

**Maximum current:  $I_{MAX}=V/R=50\text{ mA}$**




Connection with current transformer (in this case, configure the Z203-1 using software, NOT dip-switch)

The Z203-1 module allows to control a single-phase load connected to the electric network. To use the Z203-1 for high power devices, it is possible to connect a current transformer.



#### WARNING

Only the connection shown in the following figure is allowed, if a current transformer need to be connected.



Screw terminal 7 is open.

Parameters of current transformer CT are shown in the following table.

|             |                        |
|-------------|------------------------|
| <b>P1/K</b> | Primary wound input    |
| <b>P2/L</b> | Primary wound output   |
| <b>S2/K</b> | Secondary wound input  |
| <b>S2/L</b> | Secondary wound output |

## Dip-switches table



In the following tables: box without circle means Dip-Switch=0 (OFF state); box with circle means Dip-Switch=1 (ON state).

| BAUD-RATE (Dip-Switches: SW1) |   |                      |   |   |   |   |
|-------------------------------|---|----------------------|---|---|---|---|
| 1                             | 2 | Meaning              |   |   |   |   |
|                               |   | Baud-rate=9600 Baud  |   |   |   |   |
|                               | ● | Baud-rate=19200 Baud |   |   |   |   |
| ●                             |   | Baud-rate=38400 Baud |   |   |   |   |
| ●                             | ● | Baud-rate=57600 Baud |   |   |   |   |
| ADDRESS (Dip-Switches: SW1)   |   |                      |   |   |   |   |
| 3                             | 4 | 5                    | 6 | 7 | 8 | Meaning   |
|                               |   |                      |   |   |   | <b>Address and Baud-Rate are acquired from memory(EEPROM)</b> |
|                               |   |                      |   |   | ● | Address=1   |
|                               |   |                      |   | ● |   | Address=2   |
|                               |   |                      |   | ● | ● | Address=3   |
|                               |   |                      | ● |   |   | Address=4   |
| X                             | X | X                    | X | X | X |   |
| ●                             | ● | ●                    | ● | ● | ● | Address=63  |

| NOMINAL FREQUENCY (Dip-Switches: SW2)                                |         |                             |  |
|--|---------|-----------------------------|--|
| 1  | Meaning |                             |  |
|  | 50Hz    |                             |  |
| •  | 60Hz    |                             |  |
| OUTPUT TYPE (Dip-Switches: SW2)                                      |         |                             |  |
| 2  | 3       | Meaning                     |  |
|  |         | Output=0..10V               |  |
|  | •       | Output=0..5V                |  |
| •  |         | Output=0..20mA              |  |
| •  | •       | Output=4..20mA              |  |
| RETRANSMISSIONS SCALING/OUT. RANGE (Dip-Switches: SW2)               |         |                             |  |
| 4  | 5       | Meaning                     |  |
|  |         | Rescaled=100% (see table 1) |  |
|  | •       | Rescaled=50% (see table 1)  |  |
| •  |         | Rescaled=25% (see table 1)  |  |
| •  | •       | Not allowed                 |  |
| SELECTION OF QUANTITY RETRANSMITTED/RETR. OUTPUT (Dip-Switches: SW2) |         |                             |  |
| 6  | 7       | 8                           | Meaning  |
|  |         |                             | Not allowed ( <b>configuration by EEPROM if SW2-1..8 are all «0»</b> ) |
|  |         | •                           | Retransmission of RMS voltage  |
|  | •       |                             | Retransmission of RMS current  |
|  | •       | •                           | Retransmission of Active power   |
| •  |         |                             | Retransmission of CosΦ   |
| •  |         | •                           | Retransmission of Frequency  |
| •  | •       |                             | Retransmission of Reactive power                                       |
| •  | •       | •                           | Not allowed  |

| RS485 TERMINATOR (Dip-Switches: SW3) |   |                           |
|--------------------------------------|---|---------------------------|
| 1                                    | 2 | Meaning                   |
|                                      |   | RS485 terminator disabled |
| •                                    |   | RS485 terminator enabled  |

The measure ranges for RMS voltage, RMS current, active power, reactive power,  $\cos\Phi$ , frequency are shown in the following table, if configuration by Dip-Switch.



RMS voltage, RMS current, active power, frequency are measured by Z203-1 directly; energy, reactive power,  $\cos\Phi$  are obtained through processing by Z203-1.

| Possible measures | Retransmitted output range (100%) |          | Retransmitted output range (50%) |          | Retransmitted output range (25%) |         |
|-------------------|-----------------------------------|----------|----------------------------------|----------|----------------------------------|---------|
|                   | Min                               | Max      | Min                              | Max      | Min                              | Max     |
| RMS voltage       | 0Vac                              | 500Vac   | 0 Vac                            | 250Vac   | 0 Vac                            | 125Vac  |
| RMS current       | 0A                                | 5A       | 0A                               | 2.5A     | 0A                               | 1.25A   |
| Active power      | 0W                                | 2500W    | 0W                               | 1250 W   | 0 W                              | 625W    |
| Reactive power    | 0VAR                              | 2500 VAR | 0 VAR                            | 1250 VAR | 0 VAR                            | 625 VAR |
| Cos $\Phi$        | 0                                 | 1        | 0                                | 0.5      | 0                                | 0.25    |
| Frequency         | 35Hz                              | 65Hz     | 45Hz                             | 75Hz     | 40 Hz                            | 60Hz    |

**Table 1 – Measure range configurable from Dip-Switch (see the dip-switch table)**

| Physical value                        | Range of normalized value |
|---------------------------------------|---------------------------|
| VRMS from 0 to 500 V                  | 0..10000                  |
| IRMS from 0 to 5 A                    | 0..10000                  |
| WATT from 0 to 2500 W                 | 0..10000                  |
| Reactive power from -2500 to 2500 VAR | 0..10000 (*)              |
| Power factor from -1 to 1             | 0..10000 (**)             |
| Frequency from 35 Hz to 75 Hz         | 350..750                  |

**Table 2 – Range of normalized measures**

(\*) For example: if reactive power is -2500 VAR (physical value, electric line), corresponding numeric value is +10000 and retransmitted output (available at the screw terminals) is +10 V (if SW2-2,3="00").

If reactive power is 0 VAR (physical value, electric line), corresponding numeric value is 0 and retransmitted output (available at the screw terminals) is 0 V (if SW2-2,3="00").

If reactive power is +2500 VAR (physical value, electric line), corresponding numeric value is +10000 and retransmitted output (available at the screw terminals) is +10 V (if SW2-2,3="00").

(\*\*) The same behavior of reactive power.

### **IMPORTANT!**

If all the dip-switch of SW2 are equal to zero, so "00000000": the module acquires the configuration from EEPROM for: nominal frequency, output-type, output-electric value, retransmitted output, electric start scale, electric end scale (see the modbus registers).

If at least one dip-switch of SW2 is different from zero: the module acquires only the configurations applicable from dip-switch SW2. For example: if SW2 is equal to “1 | 00 | 00 | 001”, then the nominal frequency is configured as “60 Hz” from dip-switch, the output type is configured as “0..10 V” from dip-switch, the retransmission scaling is configured as “100%” and the retransmitted output is VRMS. In this case, the content of the registers 40110/40111, 40112/40113 (retransmitted output range), 40114/40115, 40116/40117 (analogue output range) are not acquired for the scaling.

## RS485 Register table

| Name   | Range   | Interpretation of register | R/W | Default | Address    |
|--|---|----------------------------|-----|---------|------------|
| MachineID  | /   | MSB, LSB                   | R   |         | 40001      |
|  | Id_Code (Module ID)   |                            |     |         | Bit [15:8] |
|  | Ext_Rev (Module version)  |                            |     |         | Bit [7:0]  |
| FWREV  | /   | Word                       | R   |         | 40005      |
|  | Firmware Code   |                            |     |         |            |
| Status   | /   | Bit                        | R/W |         | 40093      |
|  | Reset of module: 0x65 (101 decimal)=activated; any other number=deactivated   |                            |     | /       | Bit [15:8] |
|  | Input voltage: 0=voltage > 40 Vrms; 1=voltage < 40 Vrms   |                            |     | /       | Bit 7      |
|  | These bits aren't used  |                            |     | /       | Bit [6:5]  |
|  | Hardware error: 0=there isn't; 1=there is   |                            |     | /       | Bit 4      |
|  | These bits aren't used  |                            |     | /       | Bit [3:1]  |
|  | Communication error with FeRAM: 0=there isn't; 1=there is   |                            |     | /       | Bit 0      |
| Baudrate Delay   | /   | MSB, LSB                   | R/W |         | 40003      |
|  | Baud-rate for RS485 (baud-rate of module/node if parameters are configured by memory modality): 0=4800; 1=9600; 2=19200; 3=38400; 4=57600; 5=115200; 6=1200; 7=2400                                     |                            |     | 38400   | Bit [15:8] |
|  | Delay for RS485 (delay of communication response: it represents the number of the pauses(*) between the end of Rx message and the start of Tx message): from 0x00=0 to 0xFF=255 (*)1 pause=6 characters |                            |     | 0       | Bit [7:0]  |
| Address Parity   | Address: from 0x01=1 to 0xFF=255  | MSB, LSB                   | R/W |         | 40002      |
|  | Address for RS485 (address of module/node if parameters are configured by memory modality)  |                            |     | 1       | Bit [15:8] |
|  | Parity for RS485: 0=there isn't; 1=even; 2=odd  |                            |     | 0       | Bit [7:0]  |
| Nominal Frequency  |   | Word                       | R/W |         | 40007      |
|  | If Dip-Switches SW2 are equal to “00000000”: 0=50 Hz; 1=60 Hz   |                            |     |         |            |
| <b>CONFIGURATION OF RETRANSMITTED QUANTITY (ALTERNATIVE TO DIP-SWITCH)</b> |   |                            |     |         |            |
| Measured quantity on electric-line   |   | Word                       | R/W |         | 40009      |
|  | If Dip-Switches SW2 are equal to “00000000”: quantity retransmitted is: 0=VRMS; 1=IRMS; 2=potentiometer;  |                            |     |         |            |




|  |   |             |     |           |       |
|--|---|-------------|-----|-----------|-------|
|  | 3=cosfi; 4=frequency; 5=VAR; otherwise: see the Dip-switch table  |             |     |           |       |
| Start scale electric MSW                                 |   | FP32bit_MSW | R/W |           | 40110 |
| Start scale electric LSW                                 |   | FP32bit_LSW | R/W |           | 40111 |
|  | Electrical start scale value (if SW2 is "00000000"). To know which input is acquired, see reg.40009   |             |     |           |       |
| Stop scale electric MSW                                  |   | FP32bit_MSW | R/W |           | 40112 |
| Stop scale electric LSW                                  |   | FP32bit_LSW | R/W |           | 40113 |
|  | Electrical stop scale value (if SW2 is "00000000"). To know which input is acquired, see reg.40009  |             |     |           |       |
| CT Ratio   |   | Word        | R/W |           | 40004 |
|  | Transformation ratio for possible current transformer connected to input (CT). If there isn't, reg.40004=10 (CT=1); if there is, reg.40004=10*CT (retransmission is not influenced by CT value, if configuration from Dip-switch) |             |     | 10 (CT=1) |       |
| CONFIGURATION OF OUTPUT TYPE (ALTERNATIVE TO DIP-SWITCH) |   |             |     |           |       |
| Output type  |   | Word        | R/W |           | 40008 |
|  | If SW2 are equal to "00000000", analogue output is: 0=voltage; 2=current. In this case, start scale output is reg.40114/40115, end scale output is reg.40116/40117  |             |     |           |       |
| Start scale output MSW                                   |   | FP32bit_MSW | R/W |           | 40114 |
| Start scale output LSW                                   |   | FP32bit_LSW | R/W |           | 40115 |
|  | Output start scale value. To know the analogue output, see reg.40008 (if SW2 are equal to "00000000")   |             |     |           |       |
| Stop scale output MSW                                    |   | FP32bit_MSW | R/W |           | 40116 |
| Stop scale output LSW                                    |   | FP32bit_LSW | R/W |           | 40117 |
|  | Output stop scale value. To know the analogue output, see reg.40008 (if SW2 are equal to "00000000")  |             |     |           |       |
| VOLTAGE  |   |             |     |           |       |
| Voltage MSW  |   | FP32bit_MSW | R   |           | 40081 |
| Voltage LSW  |   | FP32bit_LSW | R   |           | 40082 |
|  | Retransmitted output is RMS voltage [Vrms]. This value is regardless of reg.40004   |             |     | /         |       |
| Voltage  | 0..10000  | Word        | R   |           | 40095 |
|  | RMS voltage: normalized measure of retransmitted output. This value is regardless of reg.40004  |             |     | /         |       |
| CURRENT  |   |             |     |           |       |
| Current MSW  |   | FP32bit_MSW | R   |           | 40083 |
| Current LSW  |   | FP32bit_LSW | R   |           | 40084 |
|  | Retransmitted output is RMS current [Arms]. This value depends on reg.40004   |             |     | /         |       |
| Current  | 0..10000  | Word        | R   |           | 40096 |
|  | RMS current: normalized measure of retransmitted output. This value is regardless of reg.40004  |             |     | /         |       |
| ACTIVE POWER   |   |             |     |           |       |
| Active Power MSW   |   | FP32bit_MSW | R   |           | 40085 |
| Active Power LSW   |   | FP32bit_LSW | R   |           | 40086 |
|  | Retransmitted output is Active power [W]. This value depends on reg.40004   |             |     | /         |       |

|                                 |  |                       |     |   |       |
|---------------------------------|--|-----------------------|-----|---|-------|
| Active power                    | 0..10000   |                       | R   |   | 40097 |
|                                 | Active power: normalized measure of retransmitted output. This value is regardless of reg.40004  |                       |     | / |       |
| REACTIVE POWER                  |  |                       |     |   |       |
| Reactive Power MSW              |  | FP32bit_MSW           | R   |   | 40089 |
| Reactive Power LSW              |  | FP32bit_LSW           | R   |   | 40090 |
|                                 | Retransmitted output is RMS reactive power [VARrms]. This value depends on reg.40004   |                       |     | / |       |
| Reactive power                  | 0..10000 ( <b>absolute value</b> )   |                       | R   |   | 40098 |
|                                 | RMS reactive power: normalized measure of retransmitted output. This value is regardless of reg.40004  |                       |     | / |       |
| COSΦ                            |  |                       |     |   |       |
| CosΦ MSW                        |  | FP32bit_MSW           | R   |   | 40091 |
| CosΦ LSW                        |  | FP32bit_LSW           | R   |   | 40092 |
|                                 | CosΦ electrical measure of input   |                       |     | / |       |
| CosΦ                            | 0..10000 ( <b>absolute value</b> )   |                       | R   |   | 40099 |
|                                 | CosΦ normalized measure of input. This value is regardless of reg.40004  |                       |     | / |       |
| FREQUENCY                       |  |                       |     |   |       |
| Freq MSW                        |  | FP32bit_MSW           | R   |   | 40087 |
| Freq LSW                        |  | FP32bit_LSW           | R   |   | 40088 |
|                                 | Retransmitted output is Frequency [Hz]   |                       |     |   |       |
| Frequency                       | 350..750   |                       | R   |   | 40101 |
|                                 | Frequency: normalized measure of retransmitted output. 350 corresponds to 35 Hz, 750 corresponds to 75 Hz  |                       |     |   |       |
| ENERGY                          |  |                       |     |   |       |
| Energy MSW                      |  | Signed long           | R   |   | 40079 |
| Energy LSW                      |  | Signed long           | R   |   | 40080 |
|                                 | Energy measure [W/h]   |                       |     |   |       |
| OTHER PARAMETERS                |  |                       |     |   |       |
| Command                         |  | Word                  | R/W |   | 40102 |
|                                 | 0xBACA: it loads the value of command aux in the energy register   |                       |     |   |       |
| CommandAux MSW                  |  | Word                  | R/W |   | 40103 |
| CommandAux LSW                  |  | Word                  | R/W |   | 40104 |
|                                 | Energy value that can be overwritten to the reg.40079, 40080 (see reg.40102)   |                       |     |   |       |
| Digital output energy ratio MSW |  | Unsigned long, MSW    | R/W |   | 40118 |
| Digital output energy ratio LSW |  | Unsigned long, LSW    | R/W |   | 40119 |
|                                 | Digital output energy ratio. It allows to set the partition coefficient through which a pulse is generated. If it is equal to 1, the pulse is generated when energy is incremented of a unit; if it is equal to 10, the pulse is generated when energy is incremented of 10 units; etc |                       |     |   |       |
| Energy ratio MSW                |  | Floating, 32 bit, MSW | R   |   | 40120 |
| Energy ratio LSW                |  | Floating, 32 bit, LSW | R   |   | 40121 |
|                                 | Energy ratio. It allows to set the partition coefficient through which the energy counter is incremented. If it is   |                       |     |   |       |

|  |  |  |  |
|--|--|--|--|
|  | equal to 1, the energy is counted as W/h; if it is equal to 1000, the energy is counted as kW/h, etc If it is 3600: the energy is counted as W/s |  |  |
|--|--|--|--|

## How to interpret the quantities

NOTE: In the following figures, “A”, “B”, “A1”, “B1”, “C”, “D” are references for the table 3.



(\*) Limit values of voltage, current, cosfi depend on the dip-switch SW2-4,5. In the previous figures are shown the limits related to 100% retransmission scaling.

As you can see in the following table, there are two alternative modalities to configure the Z203-1: by RS485 registers or by Dip-Switch SW2.

| Ref. | FEATURE  | Rs485 Registers (**) | Dip-switch |
|------|--|----------------------|------------|
| /    | Retransmitted quantity:<br>VRMS, ARMS, W, VAR, cosfi, Hz | 40009                | SW2-6,7,8  |
| A,A1 | Start scale of retr. quantity                            | 40110/40111          | SW2-4,5    |
| B,B1 | Stop scale of retr. quantity                             | 40112/40113          | SW2-4,5    |
| /    | Rescaled value (0..10000 or 350..750)                    | Read: 40095..40101   | /          |
| /    | Type of analog output:<br>voltage or current             | 40008                | SW2-2,3    |
| C    | Start scale of analog output: V or mA                    | 40114/40115          | SW2-2,3    |
| D    | Stop scale of analog output: V or mA                     | 40116/40117          | SW2-2,3    |

**Table 3 – Two alternative modalities to configure the Z203-1: by registers or Dip-switch**

(\*\*)If SW2=»00000000«, all the configurations are acquired from registers. If start/stop scale value of analogue output (C,D) are configured from Dip-Switch, start scale (for example: 4 mA) corresponds to the rescaled value=0 and stop scale (for example: 20 mA) corresponds to the rescaled value=10000.

## ***LEDs for signalling***

In the front-side panel there are 4 LEDs and their state refers to important operating conditions of the module.

| LED | LED status     | Meaning  |
|-----|----------------|--|
| PWR | Constant light | The power is on  |
| ERR | Blinking light | Measure of voltage: < 40 Vac and < 20 mA                                     |
|     | Constant light | The module has at least one of the errors described in RS485 Registers table |
| RX  | Constant light | Verify if the bus connection is corrected                                    |
|     | Blinking light | The module received a data packet  |
| TX  | Blinking light | The module sent a data packet  |

## ***Easy-SETUP***

To configure the Seneca Z-PC Line modules, it is possible to use Easy-SETUP software,

Free-downloadable from the [www.seneca.it](http://www.seneca.it); the configuration can be performed by RS232 or RS485 bus communication.